



Cal.GL32 Parts List

Battery	280-340
Battery clamp	234-C47
Cannon pinion with driving wheel	028-335
Center wheel cock	711-279
Clutch wheel	064-101
Coil unit	246-A24
Electric circuit unit	279-M07
Fifth wheel and pinion	084-860
Fourth wheel and pinion	023-371
Hour wheel	075-535
Hour wheel guard	176-A15
Minute wheel and pinion	072-131
Rotor	285-226
Screw for battery clamp	922-204
Screw for coil unit	922-204
Screw for electric circuit unit	922-204
Setting lever spring	019-260
Setting stem	065-541
Setting wheel	076-700
Stator	190-A31
Third wheel and pinion	017-167
Train wheel bridge	701-K01
Yoke (Train wheel setting lever)	292-360
** Longer setting stem (22.0mm) **	065-A09