

# MIYOTA

UNIVERSAL MASTERPIECE BORN IN JAPAN

MADE IN JAPAN

METAL MOVEMENT

INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT

CALIBRE NO. 6T33/8N33

HAND-WINDING & FULL SKELTON MOVEMENT


---

A) DISPLAYS AND BUTTONS

B) WINDING THE MAINSPRING

C) SETTING THE TIME

A) DISPLAYS AND BUTTONS



B) WINDING THE MAINSPRING

Manual winding watch can be wound by turning the crown clockwise in Normal position.

Wind several times clockwise. It will start to move naturally.

※ When the mainspring is full-winded (35~39 rotations of the crown are needed), stop turning the crown.

If not to stop, it can be a cause of trouble.

C) SETTING THE TIME

1. Pull the crown out to the 1st Click Position.

2. Turn the crown to set hour and minute hands.

3. After the time has been set, push the crown back to the Normal position.

*These specifications might be changed without prior notice.*

**CITIZEN WATCH CO., LTD.**

# MIYOTA


诞生于日本的世界通用机械机芯  
日本制造  
金属机芯

MIYOTA机心操作手册  
型号 6T33/8N33  
手动上条&全镂空机械机芯

---

- 1) 显示和按钮
- 2) 上发条
- 3) 校时

- 1) 显示和按钮



## 2) 上发条

顺时针转动正常位置上的柄头即可上发条

一般来说顺时针转动几下, 就开始走针。

一旦上满发条(一般来说转动35-39下), 请立刻停止转动柄头, 否则会损坏手表。

## 3) 校时

1. 将柄头拉至一档位置
2. 转动柄头调整时针和分针。
3. 调整后, 把柄头推回正常位置。

上述数值如有变更恕不另行通知  
CITIZEN WATCH CO., LTD.