


MIYOTA

UNIVERSAL MASTERPIECE BORN IN JAPAN
MADE IN JAPAN
METAL MOVEMENT

INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT CALIBRE NO. 91XX AUTOMATIC MOVEMENT

- 1) DISPLAYS AND BUTTONS
- 2) WINDING THE MAINSPRING
- 3) ADJUSTING DAY
- 4) ADJUSTING DATE
- 5) ADJUSTING TIME
- 6) ADJUSTING MONTH

1) DISPLAYS AND BUTTONS



2) WINDING THE MAINSPRING

Automatic winding watch can be also manual-winded by turning the crown in "A" position.
Wind 15 ~ 20 times clockwise until second hand starts to move naturally.

3) ADJUSTING DAY (Cal. 9100 / 9110 / 9120 / 9122)

Adjust the day by rotating the crown counter-clockwise in "B" position.

4) ADJUSTING DATE

Adjust the date by rotating the crown clockwise in "B" position.

5) ADJUSTING TIME

Rotate the crown in "C" position and adjust the standard time.
Then check if it is morning or afternoon and adjust correctly.

6) ADJUSTING MONTH (Cal. 9100 / 9120 / 9122)

Push the button "D" and adjust the month.

※If the button is not pushed to the end, the month is not changed perfectly.

These specifications might be changed without prior notice.

CITIZEN WATCH CO., LTD.

MIYOTA

诞生于日本的世界通用机械机心
日本制造
金属机心


MIYOTA机心操作手册

型号 91XX

自动机械机心

- 1) 显示和按钮
- 2) 上发条
- 3) 调整星期历
- 4) 调整日历
- 5) 校时
- 6) 调整月历

1) 显示和按钮



2) 上发条

自动表也可以通过手动上发条，顺时针转动位于正常位置的柄头即可转十五至二十下，秒针即开始走动。

3) 调整星期历 (Cal. 9100 / 9110 / 9120 / 9122)

柄头拉到第一档，逆时针转动调整星期历

4) 调整日历

柄头拉到第一档，顺时针转动调整星期历

5) 校时

柄头拉到第二档调整时间，并确认上午或下午的钟点。

6) 调整月历 (Cal. 9100 / 9120 / 9122)

按月历调节钮，即D按钮调整月历

※如果按钮没有按到底的话，月历针可能会不跳动。

上述数值如有变更恕不另行通知
CITIZEN WATCH CO., LTD.