



## Cal.JS15 Parts List

Battery connector spring	231-368
Calendar corrector wheel	213-615
Calendar platform	713-158
Cannon pinion with driving wheel	028-A19
Clutch wheel	064-790
Coil unit	246-A16
Coil unit for chronograph	246-A33
Date dial	108-K8XX
Date dial driving wheel	103-A11
Date dial maintaining plate	293-A15
Date jumper	109-873
Electric circuit unit	279-J99
Fifth wheel and pinion	084-700
Fourth wheel and pinion	023-A25
Hour wheel	075-A59
Insulator for battery connector spring	230-220
Intermediate date correcting wheel (1)	087-184
Intermediate date correcting wheel (2)	087-A52
Intermediate date correcting wheel (3)	087-997
Intermediate date correcting wheel (4)	087-997
Intermediate date correcting wheel (5)	087-A90
Intermediate minute recording wheel (1)	087-A86
Intermediate minute recording wheel (2)	087-A87
Intermediate minute recording wheel (3)	087-A88
Intermediate second recording wheel (1)	087-A84
Intermediate second recording wheel (2)	087-A85
Intermediate second recording wheel (3)	087-A85
Intermediate wheel for 24h	087-A91
Intermediate wheel for date	087-A89
Minute recording wheel	291-212
Minute wheel and pinion	072-121
Rotor	285-175
Rotor for second chronograph	285-A21
Screw for chronograph coil unit	922-166
Screw for date dial maintaining plate (x3)	929-809
Screw for electric circuit of chronograph (x2)	922-166
Screw for electric circuit unit	923-107
Screw for plate complete (2)	934-551
Screw for supporter of electric circuit unit 1(x5)	922-149
Screw for supporter of electric circuit unit (2)	923-114
Screw for train wheel bridge	923-112
Second chronograph wheel	251-321
Setting lever	067-173
Setting lever spring	077-136
Setting stem	065-505
Setting wheel	076-640
Spacer for intermediate date correcting wheel	212-A52
Spacer for setting stem	212-A53
Spacer for switch click stop spring (1)	212-A50
Spacer for switch click stop spring (2)	212-A51
Stator	190-A09
Stator for chronograph	190-A03
Switch click stop lever (1)	270-153
Switch click stop lever (2)	270-153
Switch click stop spring (1)	267-204
Switch click stop spring (2)	267-204
Third wheel and pinion	017-149
Train wheel bridge	701-H21
Train wheel bridge for chronograph	701-H22
Wheel for 24h	189-161
Yoke	071-136
** Longer setting stem(24.0mm) **	065-508