



Cal.8N24 Parts List

| | |
|--|---------|
| Balance cock complete | 350-043 |
| Balance cock complete (Semi finished) | 710-209 |
| Balance with hairspring regulated | 039-102 |
| Barrel bridge | 701-977 |
| Barrel complete | 001-870 |
| Brake lever for second hand | 269-408 |
| Casing clamp (x2)(Option) | 082-060 |
| Center wheel and pinion | 012-168 |
| Center wheel cock | 711-074 |
| Click | 060-390 |
| Click spring | 903-A04 |
| Clutch wheel | 064-450 |
| Crown wheel | 058-360 |
| Dial washer | 078-140 |
| Escape wheel and pinion | 032-106 |
| Fourth wheel and pinion | 023-940 |
| Friction spring for sweep sec pinion | 903-690 |
| Hour wheel | 075-213 |
| Hour wheel guard | 176-111 |
| Intermediate wheel | 087-250 |
| Jeweled pallet fork and staff | 035-560 |
| Lower cap jewel mounted | 094-040 |
| Minute wheel and pinion | 072-520 |
| Minute wheel guard | 079-890 |
| Oscillating weight | 119-A17 |
| Pallet cock | 708-101 |
| Pawl winding wheel | 141-190 |
| Ratchet sliding wheel spring | 078-150 |
| Ratchet wheel | 059-560 |
| Reduction wheel | 088-120 |
| Screw for barrel and train wheel bridge (x3) | 924-460 |
| Screw for center wheel cock (1)(x2) | 923-600 |
| Screw for click | 924-460 |
| Screw for click spring | 923-600 |
| Screw for dial (x2) | 929-610 |
| Screw for hour wheel guard (x3) | 923-630 |
| Screw for minute train cover (x2) | 923-630 |
| Screw for oscillating weight | 925-490 |
| Screw for pallet bridge | 923-600 |
| Screw for setting lever spring | 923-640 |
| Screw for stud | 920-010 |
| Screw for yoke | 923-640 |
| Screw for balance bridge | 924-460 |
| Second hand brake connection lever | 273-201 |
| Setting lever | 067-991 |
| Setting lever spring | 077-690 |
| Setting stem | 065-212 |
| Setting wheel | 076-430 |
| Spiral spring with jewel (x2) | 098-090 |
| Sweep second pinion | 025-790 |
| Third wheel and pinion | 017-760 |
| Upper cap jewel mounted | 094-010 |
| Yoke | 071-A04 |
| ** Longer setting stem (24.0mm) ** | 065-A06 |