



## Cal.JP27 Parts List

Battery	280-340
Battery connector spring	231-368
Calendar corrector wheel	213-615
Calendar platform	713-165
Cannon pinion with driving wheel	028-A19
Clutch wheel	064-790
Coil unit	246-A16
Date dial	108-K8XX
Date dial driving wheel	103-A11
Date dial maintaining plate	293-A38
Date jumper	109-873
Day dial	200-163
Day dial driving wheel	203-201
Day jumper	209-251
Electronic circuit unit	279-K41
Fifth wheel and pinion	084-700
Fourth wheel and pinion	023-A25
Hour wheel	075-B06
Insulator for battery connector spring	230-220
Intermediate date correcting wheel (1)	087-184
Intermediate date correcting wheel (2)	087-A52
Intermediate date correcting wheel (3)	087-997
Intermediate date correcting wheel (4)	087-997
Intermediate date correcting wheel (5)	087-A90
Intermediate wheel for date (1)	087-A89
Intermediate wheel for date (2)	087-A91
Rotor	285-175
Screw for date dial maintaining plate (x3)	929-809
Screw for electric circuit unit	923-107
Screw for plate complete (2)	934-551
Screw for supporter of electric circuit unit (1)(x4)	922-149
Screw for supporter of electric circuit unit (2)	923-114
Screw for train wheel bridge	923-112
Setting lever	072-121
Setting lever	067-173
Setting lever spring	077-136
Setting stem	065-505
Setting wheel	076-640
Spacer for intermediate date correcting wheel	212-A52
Spacer for setting stem	212-A53
Spacer for switch click stop spring	212-A50
Stator	190-A09
Supporter for electric circuit unit	720-B94
Switch click stop spring	267-204
Third wheel and pinion	017-149
Train wheel bridge	701-H21
Yoke	071-136
** Longer setting stem (24.0mm) **	065-508