



## Cal.2005 Parts List

Battery	280-390
Battery clamp	234-838
Calender correct intermediate wheel	087-420
Calender corrector lever	116-360
Calender corrector wheel	213-200
Cannon pinion with driving wheel	028-600
Center wheel cock	711-100
Circuit spacer (Spacer for setting stem)	212-319
Clutch wheel	064-660
Clutch wheel guard	212-200
Coil unit	246-144
Date dial	108-75XX
Date dial driving wheel	103-760
Date dial guard	293-340
Date jumper	109-430
Day dial gib	178-140
Day of week dial	308-46XX
Electronic circuit unit	279-H89
Fifth wheel and pinion	084-190
Fourth wheel and pinion	023-154
Hour wheel	075-192
Minute wheel and pinion	072-760
Powercell connector spring	231-105
Rotor	285-202
Screw for coil unit	922-183
Screw for date dial guard (x3)	929-390
Screw for electronic circuit unit (1)	922-183
Screw for electronic circuit unit (2)	922-154
Screw for train wheel bridge (1)	922-154
Screw for train wheel bridge (2)	934-440
Setting lever	067-145
Setting stem	065-299
Stator	190-420
Third wheel and pinion	017-103
Train wheel bridge	701-933
Yoke	071-998
** Longer setting stem (21.0mm) **	065-371
** Longer setting stem (24.0mm) **	065-511
** Longer setting stem (33.7mm) **	065-994