



## Cal.2317 Parts List

Battery	280-390
Battery clamp	234-C20
Battery connector spring	231-105
Calendar plate	714-061
Canon pinion with driving wheel	028-990
Center wheel cock	711-100
Clutch wheel	064-660
Clutch wheel guard	212-200
Coil unit	246-144
Corrector intermediate wheel	087-420
Corrector lever	116-125
Corrector wheel	213-200
Date dial	108-H1X
Date dial driving wheel	103-126
Date dial guard	293-128
Electronic circuit unit	279-H89
Fifth wheel and pinion	084-190
Fourth wheel and pinion	023-188
Hour wheel	075-A01
Jumper	109-430
Minute wheel and pinion	072-760
Rotor	285-202
Screw for coil unit	922-183
Screw for date dial guard	922-194
Screw for electronic circuit unit (1)	922-183
Screw for electronic circuit unit (2)	922-154
Screw for train wheel bridge (1)	922-154
Screw for train wheel bridge (2)	934-440
Setting lever	067-145
Setting stem	065-299
Spacer	212-319
Stator	190-420
Third wheel and pinion	017-103
Train wheel bridge	701-933
Yoke	071-998
** Longer setting stem (21.0mm) **	065-371
** Longer setting stem (24.0mm) **	065-511
** Longer setting stem (33.7mm) **	065-994