



Cal.0T50 Parts List

Battery	280-440
Battery clamp	234-C39
Battery connector spring	231-345
Calendar corrector lever	116-994
Calendar corrector wheel	213-380
Calendar plate	714-075
Cannon pinion with driving wheel	028-A50
Clutch wheel	064-670
Coil unit	246-147
Date dial	108-L0XX
Date dial driving wheel	103-A14
Date dial guard	293-A20
Date jumper	109-580
Day dial	308-B8XX
Day dial guard	117-359
Electronic circuit unit	279-J17
Fifth wheel and pinion	084-640
Fourth wheel and pinion	023-267
Hour wheel	075-A71
Intermediate date correcting wheel	087-620
Intermediate minute wheel	087-138
Minute wheel and pinion	072-114
Rotor	285-223
Screw for battery strap (x4)	923-980
Screw for coil unit	923-990
Screw for date dial guard (1) (x2)	929-650
Screw for date dial guard (2)	922-A02
Screw for day dial guard	929-814
Screw for electric circuit	923-990
Screw for train wheel bridge (x3)	923-980
Second wheel	025-114
Setting lever	067-993
Setting stem	065-453
Setting wheel	076-680
Spacer for electric circuit (1) (x2)	027-111
Spacer for electric circuit (2)	027-112
Spacer for setting stem	212-A54
Stator	190-126
Supporter for plate complete	226-497
Third wheel and pinion	017-142
Train wheel bridge	701-J61
Yoke	071-128
** Longer setting stem (24.00mm length of thread:10mm) **	065-557
** Longer setting stem (24.00mm length of thread:5.3mm) **	065-533