



Cal. 9075 Instruction manual


1) DISPLAYS AND BUTTONS

2) WINDING THE MAINSPRING

3) ADJUSTING DATE AND TIME

4) ADJUSTING LOCAL TIME

1) DISPLAYS AND BUTTONS



2) WINDING THE MAINSPRING

Automatic winding watch can be also manual-winded by turning the crown in "A" position.

Wind 15~20 times clockwise until second hand starts to move naturally.

3)ADJUSTING DATE AND TIME

Turn the crown in position "C" to set the 24 hour and minute hands to home time.

Return the crown to position "A",

then turn the crown in position "B" to set the hour hand and date to local time.

*When the hour hand turns twice, the date will change by one day.

*When setting the time, pay attention to AM or PM.

*When setting the time anticlockwise between 21:00 and midnight,
set it back until the date switches to the previous day.

4) ADJUSTING LOCAL TIME

This movement allows you to change hour hand without stopping other hands.

Turn the crown at position "B" to change the hour hand by one hour.

These specifications might be changed without prior notice.