



Cal.2036 Parts List

Battery clamp	234-C96
Cannon pinion with driving wheel	028-A62
Center wheel cock	711-281
Circuit spacer (Spacer for setting stem)	212-B13
Clutch wheel	064-660
Clutch wheel guard	212-B17
Coil unit	246-144
Dial washer	078-040
Electronic circuit unit	279-M31
Fifth wheel and pinion	084-971
Fourth wheel and pinion	023-223
Fourth wheel stop lever	269-413
Hour wheel	075-304
Minute wheel and pinion	072-760
Power-cell connector spring	231-999
Rotor	285-202
Screw for coil unit	922-183
Screw for electronic circuit unit (1)	922-183
Screw for electronic circuit unit (2)	922-154
Screw for train wheel bridge (1)	922-154
Screw for train wheel bridge (2)	934-440
Setting lever	067-146
Setting stem	065-468
Stator	190-A43
Third wheel and pinion	017-A14
Train wheel bridge	701-K14
Yoke	071-A14
** Longer setting stem (21.0mm) **	065-371
** Longer setting stem (24.0mm) **	065-511
** Longer setting stem (33.7mm) **	065-994