



## Cal.6S21 Parts List

Battery connector spring	231-994
Calendar corrector wheel	213-619
Calendar plate	714-078
Cannon pinion with driving wheel	028-A32
Center wheel cock	711-248
Clutch wheel	064-970
Coil unit	246-147
Coil unit for second wheel	246-A19
Date dial	108-L8XX
Date dial driving wheel	103-A17
Date dial guard	293-A24
Date jumper	109-890
Electric circuit unit	279-K03
Fifth wheel and pinion	084-640
Fly back connection lever	260-991
Fly back lever (1)	270-157
Fly back lever (2)	270-156
Forth wheel and pinion	023-267
Hour wheel	075-A82
Intermediate 1/4 second recording wheel (1)	087-B10
Intermediate 1/4 second recording wheel (2)	087-B11
Intermediate date correcting wheel (1)	087-B19
Intermediate date correcting wheel (2)	087-B21
Intermediate date correcting wheel (3)	087-B20
Intermediate date correcting wheel (4)	087-B20
Intermediate date correcting wheel (5)	087-B17
Intermediate minute wheel (1)	087-268
Intermediate minute wheel (2)	087-268
Intermediate minute recording wheel (1)	087-B12
Intermediate minute recording wheel (2)	087-B13
Intermediate minute recording wheel (3)	087-B14
Intermediate second recording wheel (1)	087-B15
Intermediate second recording wheel (2)	087-B18
Minute recording wheel	291-222
Minute wheel and pinion	072-114
Rotor	285-A31
Rotor for 1/4 second chronograph	285-A29
Rotor for second wheel	285-A30
Screw for calendar plate (x3)	935-201
Screw for center wheel cock (x3)	923-980
Screw for chronograph guard (x6)	923-980
Screw for coil unit (6s11:x2, 6s21:x3)	923-112
Screw for date dial guard (x3)	929-650
Screw for electric circuit (6s11:x2, 6s21:x3)	923-990
Screw for magnetic shield plate (x2)	930-650
Screw for setting lever spring	922-166
Screw for setting stem cover	922-166
Screw for train wheel bridge (x3)	923-980
Second wheel	251-333
Setting lever	067-999
Setting lever spring	077-997
Setting stem	065-A13
Setting stem cover	019-361
Setting wheel	076-720
Spacer for setting stem	212-A64
Spring for supporter of 1/4 second chronograph wheel	903-A30
Stator	190-A21
Stator for 1/4 second chronograph	190-A22
Stator for second wheel	190-A23
Stop lever for fifth wheel	269-404
Supporter for chronograph plate	720-A02
Supporter for plate complete	226-A60
Switch click stop lever	270-154
Third wheel and pinion	017-142
Train wheel bridge	701-H87
Yoke	071-997
1/4 second chronograph coil unit	246-A18
1/4 second chronograph wheel	251-332