



Cal.9T15 Parts List

Battery connector spring	231-368
Battery insulator	230-220
Calendar corrector lever	116-112
Cannon pinion with driving wheel	028-301
Clutch wheel	064-790
Coil unit	246-182
Date dial	108-E5XX
Date dial driving wheel	103-111
Date jumper	109-500
Dial guard ring	110-470
Dial washer	078-040
Electric circuit unit	279-B32
Fifth wheel and pinion	084-700
Fourth wheel and pinion	023-328
Guard for date dial	293-103
Hour wheel	075-455
Intermediate wheel	087-162
Minute wheel and pinion	072-121
Rotor	285-175
Screw for coil unit	930-640
Screw for date dial guard (x3)	929-510
Screw for train wheel bridge (x2)	923-112
Setting lever	067-173
Setting lever spring	077-136
Setting stem	065-495
Setting wheel	076-640
Spacer for setting stem	212-247
Stator	190-A09
Third wheel and pinion	017-149
Yoke	071-137
** Longer setting stem (21.0mm) **	065-551