


INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT

CALIBER NO. 2037 (Counterclockwise)

BATTERY: SR626SW

INSTRUCTION MANUAL

A) DISPLAY



B) SETTING THE TIME

1. Pull the crown out to the 1st position.
2. Turn the crown to set hour and minute hands.
3. When the crown is pushed back to the normal position, second hand begins to run.