



## Cal.90S5 Parts List

|                                                      |           |
|------------------------------------------------------|-----------|
| Balance bridge                                       | 350-013   |
| Balance bridge (Semi finished)                       | 710-204   |
| Balance with hairspring regulated                    | 039-993   |
| Barrel and train wheel bridge                        | 701-J09   |
| Barrel complete                                      | 001-992   |
| Brake lever for second hand                          | 269-402   |
| Cannon pinion with driving wheel                     | 028-A16   |
| Cap jewel mounted (1)                                | 094-040   |
| Cap jewel mounted (2)                                | 094-010   |
| Casing clamp (x2)(Option)                            | 082-060   |
| Casing holder(Plastic)                               | 500-00228 |
| Center wheel and pinion                              | 012-A43   |
| Center wheel bridge                                  | 702-201   |
| Click                                                | 060-551   |
| Click spring                                         | 903-A15   |
| Clutch wheel                                         | 064-991   |
| Crown wheel                                          | 058-502   |
| Date indicator maintaining plate / Hour wheel spring | 176-A08   |
| Dial spacer                                          | 212-A47   |
| Dial washer                                          | 078-400   |
| Escape wheel and pinion                              | 032-991   |
| Fourth wheel and pinion                              | 023-A21   |
| Hour wheel                                           | 075-A51   |
| Intermediate reduction wheel and pinion (1)          | 088-254   |
| Intermediate reduction wheel and pinion (2)          | 088-252   |
| Intermediate reduction wheel and pinion (3)          | 088-253   |
| Intermediate reduction wheel and pinion (4)          | 138-252   |
| Jeweled pallet fork and staff                        | 035-706   |
| Minute wheel and pinion                              | 072-998   |
| Operating lever                                      | 257-152   |
| Oscillating weight                                   | 119-A36   |
| Pallet bridge                                        | 708-091   |
| Ratchet sliding wheel (1)                            | 087-B08   |
| Ratchet sliding wheel (2)                            | 087-C03   |
| Ratchet wheel                                        | 059-805   |
| Reduction wheel and pinion (1) spring clip           | 115-101   |
| Reversing wheel                                      | 141-251   |
| Screw for balance bridge                             | 923-998   |
| Screw for barrel and train wheel bridge (x5)         | 923-998   |
| Screw for casing clamp (x2)(Option)                  | 924-752   |
| Screw for center wheel bridge                        | 923-998   |
| Screw for click                                      | 922-820   |
| Screw for click spring                               | 922-820   |
| Screw for dial (x2)                                  | 929-808   |
| Screw for hour wheel spring (x4)                     | 930-701   |
| Screw for minute train cover (x2)                    | 923-630   |
| Screw for oscillating weight( x3)                    | 923-999   |
| Screw for pallet bridge (x2)                         | 922-820   |
| Screw for stud                                       | 927-020   |
| Screw for train wheel guard (Automatic)(x2)          | 930-701   |
| Screw for train wheel guard (Manual winding)(x3)     | 930-701   |
| Setting lever                                        | 067-995   |
| Setting lever pin                                    | 906-A12   |
| Setting lever spring                                 | 077-998   |
| Setting stem                                         | 065-A05   |
| Setting wheel                                        | 076-751   |
| Spiral spring with jewel (1)                         | 098-090   |
| Spiral spring with jewel (2)                         | 098-090   |
| Third wheel and pinion                               | 017-A11   |
| Train wheel guard (Automatic)                        | 117-354   |
| Train wheel guard (Manual winding)                   | 117-361   |
| Winding pinion                                       | 063-351   |
| Yoke                                                 | 071-999   |
| ** Longer setting stem (24.0mm) **                   | 065-A25   |