



## Cal.5Y20 Parts List

|                                    |         |
|------------------------------------|---------|
| Battery                            | 280-590 |
| Battery connector spring           | 231-174 |
| Cannon pinion with driving wheel   | 028-144 |
| Center wheel cock                  | 711-182 |
| Clutch wheel                       | 064-790 |
| Coil unit                          | 246-164 |
| Dial washer                        | 078-440 |
| Electronic circuit unit            | 279-H41 |
| Fifth wheel and pinion             | 084-690 |
| Fourth wheel and pinion            | 023-294 |
| Hour wheel                         | 075-A34 |
| Minute wheel and pinion            | 072-116 |
| Rotor                              | 285-162 |
| Screw for train wheel bridge (x3)  | 923-810 |
| Setting lever                      | 067-176 |
| Setting lever spring               | 077-115 |
| Setting stem                       | 065-403 |
| Setting wheel                      | 076-640 |
| Spacer for setting stem            | 212-165 |
| Spacer for train wheel bridge (1)  | 027-990 |
| Spacer for train wheel bridge (2)  | 027-103 |
| Stator                             | 190-145 |
| Third wheel and pinion             | 017-148 |
| Train wheel bridge                 | 701-G58 |
| Yoke                               | 071-116 |
| <br>                               |         |
| ** Longer setting stem (24.0mm) ** | 065-498 |