




Cal. 6T15 Instruction manual

A) DISPLAY



*Date position may be located at different position depends on models.

B) SETTING THE TIME

1. Pull the crown out to the 2nd position.
2. Turn the crown to set hour and minute hands.
3. When the crown is pushed back to the normal position, second hand begins to run.

C) SETTING THE DATE

1. Pull the crown out to the 1st position.
2. Pull the crown from the 1st position to the 2nd position, then date advances one day.
3. After the date has been set, push the crown back to the normal position.

These specifications might be changed without prior notice.