



Cal.0S30 Parts List

Battery	280-440
Battery connector spring	231-345
Cannon pinion with driving wheel	028-218
Center wheel cock	711-163
Chronograph coil unit	246-148
Clutch wheel	064-670
Coil unit	246-147
Electric circuit unit	279-J17
Fifth wheel and pinion	084-640
Fly back connection lever	270-060
Fly back lever	260-116
Forth wheel and pinion	023-267
Hour recording wheel	294-710
Hour wheel	075-392
Intermediate date correcting wheel	087-620
Intermediate hour recording wheel (1)	087-135
Intermediate hour recording wheel (2)	087-136
Intermediate hour recording wheel (3)	087-137
Intermediate minute wheel	087-138
Intermediate minute recording wheel	087-134
Intermediate second recording wheel	087-221
Minute recording wheel	291-060
Minute wheel and pinion	072-114
Rotor	285-223
Rotor for chronograph	285-224
Screw for center wheel cock (x3)	923-980
Screw for chronograph coil unit	923-990
Screw for chronograph guard (x4)	923-980
Screw for coil unit	923-990
Screw for electric circuit (x2)	923-990
Screw for train wheel bridge (x3)	923-980
Second chronograph wheel	251-080
Second wheel	025-950
Setting lever	067-163
Setting stem	065-453
Setting wheel	076-680
Spacer for electric circuit (1)(x2)	027-111
Spacer for electric circuit (2)	027-112
Spacer for setting stem	212-A54
Stator	190-126
Stator for chronograph	190-128
Stop lever	204-530
Supporter for plate complete	226-497
Supporter for chronograph plate	720-204
Third wheel and pinion	017-142
Train wheel bridge	701-E92
Yoke	071-A06
** Longer setting stem (24.0mm the length of thread:10.0mm) **	065-557
** Longer setting stem (24.0mm the length of thread:5.5mm) **	065-533