



## Cal. 91XX Instruction manual

---

### 1) DISPLAYS AND BUTTONS

#### 2) WINDING THE MAINSPRING


#### 3) ADJUSTING DAY

#### 4) ADJUSTING DATE

#### 5) ADJUSTING TIME

#### 6) ADJUSTING MONTH

### 1) DISPLAYS AND BUTTONS



### 2) WINDING THE MAINSPRING

Automatic winding watch can be also manual-winded by turning the crown in "A" position.  
Wind 15 ~ 20 times clockwise until second hand starts to move naturally.

### 3) ADJUSTING DAY (Cal. 9110)

Adjust the day by rotating the crown counter-clockwise in "B" position.

#### **4) ADJUSTING DATE**

Adjust the date by rotating the crown clockwise in "B" position.

#### **5) ADJUSTING TIME**

Rotate the crown in "C" position and adjust the standard time.

Then check if it is morning or afternoon and adjust correctly.

#### **6) ADJUSTING MONTH**

Push the button "D" and adjust the month.

※If the button is not pushed to the end, the month is not changed perfectly.

***These specifications might be changed without prior notice.***