



Cal.2315 Parts List

Battery clamp	234-C87
Calendar plate	714-061
Calendar corrector intermediate wheel	087-420
Calendar corrector lever	116-125
Calendar corrector wheel	213-200
Cannon pinion with driving wheel	028-A58
Center wheel cock	711-281
Circuit spacer (Spacer for setting stem)	212-B13
Clutch wheel	064-660
Clutch wheel guard	212-B17
Coil unit	246-144
Date dial	108-H1X
Date dial driving wheel	103-126
Date dial guard	293-128
Electronic circuit unit	279-M31
Fifth wheel and pinion	084-971
Fourth wheel and pinion	023-154
Fourth wheel stop lever	269-413
Hour wheel	075-545
Jumper	109-430
Minute wheel and pinion	072-760
Power-cell connector spring	231-999
Rotor	285-202
Screw for coil unit	922-183
Screw for date dial guard	922-194
Screw for electronic circuit unit (1)	922-183
Screw for electronic circuit unit (2)	922-154
Screw for train wheel bridge (1)	922-154
Screw for train wheel bridge (2)	934-440
Setting lever	067-145
Setting stem	065-299
Stator	190-A43
Third wheel and pinion	017-A14
Train wheel bridge	701-K14
Yoke	071-A15
** Longer setting stem (21.0mm) **	065-371
** Longer setting stem (24.0mm) **	065-511
** Longer setting stem (33.7mm) **	065-994