



Cal.GL12 Parts List

| | |
|---|----------|
| Battery | 280-340 |
| Battery clamp | 234-C60 |
| Calendar corrector intermediate wheel (1) | 087-113 |
| Calendar corrector intermediate wheel (2) | 087-114 |
| Calendar corrector operating wheel | 255-430 |
| Calendar plate | 714-094 |
| Cannon pinion with driving wheel | 028-336 |
| Center wheel cock | 711-256 |
| Clutch wheel | 064-101 |
| Coil unit | 246-A24 |
| Date dial (Date disk) | 108-G2XX |
| Date dial driving wheel | 103-123 |
| Date dial guard | 293-123 |
| Date jumper | 109-430 |
| Electric circuit unit | 279-M07 |
| Fifth wheel and pinion | 084-860 |
| Fourth wheel and pinion | 023-372 |
| Hour wheel | 075-B02 |
| Minute wheel and pinion | 072-131 |
| Rotor | 285-226 |
| Screw for battery clamp | 922-204 |
| Screw for coil unit | 922-204 |
| Screw for date dial guard (x2) | 929-680 |
| Screw for electric circuit unit | 922-204 |
| Setting lever spring | 019-260 |
| Setting stem | 065-547 |
| Setting wheel | 076-700 |
| Stator | 190-A31 |
| Third wheel and pinion | 017-167 |
| Train wheel bridge | 701-K01 |
| Yoke (Train wheel setting lever) | 292-360 |
| ** Longer setting stem (24.0mm) ** | 065-995 |