



Cal.203A Parts List

Battery	280-390
Battery clamp	234-838
Cannon pinion with driving wheel	028-302
Center wheel cock	711-100
Circuit spacer (Spacer for setting stem)	212-319
Clutch wheel	064-660
Clutch wheel guard	212-200
Coil unit	246-144
Dial washer	078-040
Electronic circuit unit	279-H89
Fifth wheel and pinion	084-190
Fourth wheel and pinion	023-337
Hour wheel	075-491
Minute wheel and pinion	072-760
Powercell connector spring	231-105
Rotor	285-202
Screw for coil unit	922-183
Screw for electronic circuit unit (1)	922-183
Screw for electronic circuit unit (2)	922-154
Screw for train wheel bridge (1)	922-154
Screw for train wheel bridge (2)	934-440
Setting lever	067-146
Setting stem	065-468
Stator	190-420
Third wheel and pinion	017-103
Train wheel bridge	701-933
Yoke	071-133
** Longer setting stem (21.0mm) **	065-371
** Longer setting stem (24.0mm) **	065-511
** Longer setting stem (33.7mm) **	065-994