



Cal.9132 Parts List

| | |
|--|-----------|
| Balance bridge | 710-204 |
| Balance with hairspring regulated | 039-993 |
| Barrel and train wheel bridge | 701-J09 |
| Barrel complete | 001-995 |
| Barrel lower wheel | 901-A56 |
| Brake lever for second hand | 269-402 |
| Calendar corrector finger | 106-860 |
| Calendar corrector wheel | 213-616 |
| Calendar corrector wheel spring | 903-A18 |
| Calendar platform | 713-160 |
| Cannon pinion with driving wheel | 028-A22 |
| Cap jewel mounted (1) | 094-040 |
| Cap jewel mounted (2) | 094-010 |
| Casing clamp (x2)(Option) | 082-060 |
| Center wheel and pinion | 012-A43 |
| Center wheel bridge | 702-201 |
| Click | 060-551 |
| Click spring | 903-A15 |
| Clutch wheel | 064-991 |
| Crown wheel | 058-502 |
| Date dial | 108-N4XX |
| Date dial guard | 293-A18 |
| Date jumper | 109-875 |
| Dial washer (1) | 078-400 |
| Dial washer (2) | 078-660 |
| Escape wheel and pinion | 032-991 |
| Fourth wheel and pinion | 023-A27 |
| Hour wheel | 075-A63 |
| Intermediate date correcting wheel | 087-A72 |
| Intermediate date wheel (1) | 087-A93 |
| Intermediate date wheel (2) | 087-A94 |
| Intermediate power reserve wheel (1) | 087-A95 |
| Intermediate power reserve wheel (2) | 087-A96 |
| Intermediate power reserve wheel (3) | 087-A97 |
| Intermediate power reserve wheel (4) | 087-B01 |
| Intermediate reduction wheel and pinion (1) | 088-254 |
| Intermediate reduction wheel and pinion (1)spring clip | 115-101 |
| Intermediate reduction wheel and pinion (2) | 088-252 |
| Intermediate reduction wheel and pinion (3) | 088-253 |
| Intermediate reduction wheel and pinion (4) | 138-252 |
| Jeweled pallet fork and staff | 035-702 |
| Lower plate for barrel complete | 719-058 |
| Lower plate for calender | 719-065 |
| Minute wheel and pinion | 072-999 |
| Movement holder (Plastic) | 500-00245 |
| Operating lever | 257-152 |
| Oscillating weight | 119-A60 |
| Pallet bridge | 708-091 |
| Power reserve wheel | 189-163 |
| Ratchet sliding wheel (1) | 087-B08 |
| Ratchet sliding wheel (2) | 087-C03 |
| Ratchet wheel | 059-805 |
| Reversing wheel | 141-251 |
| Screw for balance bridge | 923-998 |
| Screw for barrel and train wheel bridge (x5) | 923-998 |
| Screw for calendar platform | 929-700 |
| Screw for casing clamp (x2)(Option) | 924-752 |
| Screw for center wheel bridge | 923-998 |
| Screw for click | 922-820 |
| Screw for click spring | 922-820 |
| Screw for date dial guard | 929-700 |
| Screw for date dial guard (x4) | 930-702 |
| Screw for lower plate for barrel complete (x2) | 922-940 |
| Screw for lower plate for calender (x2) | 923-998 |
| Screw for oscillating weight (x3) | 923-999 |
| Screw for pallet bridge (x2) | 922-820 |
| Screw for setting lever jumper (x2) | 923-630 |
| Screw for stud | 927-020 |
| Screw for train wheel guard (Automatic)(x2) | 930-701 |
| Screw for train wheel guard (Manual winding)(x3) | 930-701 |
| Screw for upper plate for calender (x4) | 923-998 |
| Setting lever | 067-995 |
| Setting lever pin | 906-A12 |
| Setting lever spring | 077-996 |
| Setting stem | 065-A05 |
| Setting wheel | 076-751 |
| Spiral spring with jewel (1) | 098-090 |
| Spiral spring with jewel (2) | 098-090 |
| Third wheel and pinion | 017-A11 |
| Train wheel guard (Automatic) | 117-354 |
| Train wheel guard (Manual winding) | 117-361 |
| Upper plate for calender | 703-112 |
| Winding pinion | 063-351 |
| Yoke | 071-995 |
| 24hour driving wheel | 100-818 |
| 24hour wheel | 103-A13 |
| ** Longer setting stem (24.0mm) ** | 065-A25 |