


Cal. GL12/GL14 Instruction manual

A)DISPLAY



*Date position may be located at different position depends on models.

B) SETTING THE TIME

- 1. Pull the crown out to the 2nd position.
- 2. Turn the crown to set hour and minute hands.
- 3. When the crown is pushed back to the normal position, second hand begins to run.

C) SETTING THE DATE

- 1. Pull the crown out to the 1st position.
- 2. Turn the crown counter-clockwise to set the date.
 - * If the date is set between the hours of around 9:00 PM and 1:00 AM, the date may not change the following day.
- 3. After the date has been set, push the crown back to the normal position.

These specifications might be changed without prior notice.