MIYOTA

# Cal.0S20 Parts List

| | |
|---|---|
| Battery | 280-440 |
| Battery connector spring | 231-345 |
| Calendar corrector lever | 116-115 |
| Calendar corrector wheel | 213-440 |
| Calendar plate | 714-069 |
| Cannon pinion with driving wheel | 028-295 |
| Center wheel cock | 711-163 |
| Chronograph coil unit | 246-148 |
| Clutch wheel | 064-670 |
| Coil unit | 246-147 |
| Date dial | 108-A0XX |
| Date dial driving wheel | 103-105 |
| Date dial guard | 293-119 |
| Date jumper | 109-580 |
| Dial guard | 713-138 |
| Electric circuit unit | 279-J17 |
| Fifth wheel and pinion | 084-640 |
| Fly back connection lever | 270-060 |
| Fly back lever | 260-116 |
| Forth wheel and pinion | 023-267 |
| Hour wheel | 075-523 |
| Intermediate date correcting wheel | 087-620 |
| Intermediate date correcting wheel (2) | 087-218 |
| Intermediate date correcting wheel (3) | 087-218 |
| Intermediate date correcting wheel (4) | 087-219 |
| Intermediate fly back wheel | 087-216 |
| Intermediate hour recording wheel (1) | 087-217 |
| Intermediate minute recordimg wheel (1) | 087-135 |
| Intermediate minute recordimg wheel (2) | 087-214 |
| Intermediate minute recordimg wheel (3) | 087-215 |
| Intermediate minute wheel | 087-138 |
| Intermediate second recordimg wheel | 087-221 |
| Minute recording wheel | 291-090 |
| Minute wheel and pinion | 072-114 |
| Rotor | 285-223 |
| Rotor for chronograph | 285-224 |
| Screw for center wheel cock (x3) | 923-980 |
| Screw for chronograph coil unit | 923-990 |
| Screw for chronograph guard (x4) | 923-980 |
| Screw for coil unit | 923-990 |
| Screw for date dial guard (x3) | 929-640 |
| Screw for electric circuit (x2) | 923-990 |
| Screw for train wheel bridge (x3) | 923-980 |
| Second chronograph wheel | 251-180 |
| Second wheel | 025-114 |
| Setting lever | 067-993 |
| Setting stem | 065-453 |
| Setting wheel | 076-680 |
| Spacer for electric circuit (1)(x2) | 027-111 |
| Spacer for electric circuit (2) | 027-112 |
| Spacer for setting stem | 212-A54 |
| Stator | 190-126 |
| Stator for chronograph | 190-128 |
| Stop lever | 204-530 |
| supporter for chronograph plate | 720-526 |
| Supporter for chronograph plate | 017-142 |
| Supporter for plate complete | 226-497 |
| Third wheel and pinion | 701-E92 |
| Train wheel bridge | 071-A06 |
| Yoke | 100-670 |
| | |
| ** Longer setting stem (24.0mm the length of thread:10.0mm) ** | 065-557 |
| ** Longer setting stem (24.0mm the length of thread:5.5mm) ** | 065-533 |