


# Cal. JS10 Instruction manual

## [Displays and Buttons]



#### A) SETTING THE TIME

- 1. Pull the crown out to the 1st Click Position.
- 2. Turn the crown to set hour and minute hands.

## **B) USING THE STOPWATCH**

This stopwatch is able to measure and display time in 1/1 second united up to maximum of 30 minutes.

Stopwatch will stop automatically after running continuously for 30 minutes.

## (Measuring time with the stopwatch)

- 1. Press button "A" to start the stopwatch.
- 2. The stop watch can be started and stopped each time button "A" is pressed.
- 3. Pressing button "B" resets the stopwatch and stopwatch minute and second hands return to their Zero positions.



#### C) STOPWATCH RESET (INCL. AFTER REPLACING BATTERY)

This procedure should be performed when the stopwatch second hand does not return to the Zero second.

- 1. Pull the crown out to the 1st Click Position.
- 2. Press the button "A" to set the stopwatch second hand forward.

Press the button "B" to set the stopwatch second hand back.

- \* The stopwatch minutes hand is synchronized with stop watch second hand.
- \* The stopwatch second hand can be advanced rapidly by continuously pressing button "A" or "B".
- 3. Once the hands been zeroed, reset the time and return the crown to its normal position.

These specifications might be changed without prior notice.