


MIYOTA

UNIVERSAL MASTERPIECE BORN IN JAPAN
MADE IN JAPAN
METAL MOVEMENT

INSTRUCTION MANUAL FOR MIYOTA WATCH MOVEMENT CALIBRE NO. 9015 AUTOMATIC MOVEMENT

- 1) DISPLAYS AND BUTTONS
- 2) WINDING THE MAINSPRING
- 3) ADJUSTING TIME
- 4) ADJUSTING DATE

1) DISPLAYS AND BUTTONS



2) WINDING THE MAINSPRING

Automatic winding watch can be also manual-winded by turning the crown in "A" position.
Wind 15 ~ 20 times clockwise until second hand starts to move naturally.

3) ADJUSTING TIME

Rotate the crown in "C" position and adjust the standard time.
Then check if it is morning or afternoon and adjust correctly.

4) ADJUSTING DATE

Adjust the date by rotating the crown in "B" position.

* If the date is adjusted between the hours of around 8:30 PM and 2:00 AM the date may not change on the following day.

These specifications might be changed without prior notice.

CITIZEN WATCH CO., LTD.

MIYOTA

诞生于日本的世界通用机械机芯
日本制造
金属机芯


MIYOTA机芯操作手册

型号 9015

自动机械机芯

- 1) 显示和按钮
- 2) 上发条
- 3) 校时
- 4) 调整日历

1) 显示和按钮



2) 上发条

自动表也可以通过手动上发条，顺时针转动位于正常位置的柄头即可手动上条的话一般顺时针转十五至二十下即可。

3) 校时

1. 柄头拉至二档位置，转动柄头调整时间。
2. 确认是上午或下午的钟点。

4) 调整日历

1. 将柄头拉到一档位置，转动柄头调整日历。

* 在下午8点至凌晨2点之间调整日历的话，第二天日历可能会不跳动。请勿在上述时间段内调整日历。

上述数值如有变更恕不另行通知
CITIZEN WATCH CO., LTD.